rawinternational

CONSULT AUTHORISED SERVICE PERSONNEL FOR THE INSTALLATION OF THIS UNIT. INSTRUCTIONS MUST BE FOLLOWED PRECISELY FOR SAFE AND STABLE INSTALLATION. RAW INTERNATIONAL ARE NOT LIABLE FOR ANY DAMAGE OR INJURY CAUSED BY MISHANDLING OR IMPROPER INSTALLATION.

PSA1 INSTRUCTION MANUAL

Supplied Parts List

M4x16 x 6	M5x30 x 4	M6x35 x 4	M8 Nuts x 4
M4x20 x 6	M5x35 x 4	M8 Metal Washers x 12	Plastic Washer x 8
M5x20 x 4	M6x20 x 4	M8x30 x 4	











VESA 100



VESA 200X200 — VESA 200X100



FL1/FT1/VFT1/OFB1/OFTB1



PF1/PT1/VPT1/OPB1/OPTB1



OBF1/OBT1